



Kaser PortableVault™ drives let you quickly store and protect your valuable digital information and personal files.

Package Contents

- External hard drive
- USB Cable



System setup

For best USB performance with Windows XP and Windows 2000, use the latest service packs. For more information about service packs for Windows, visit www.microsoft.com.

Windows ME / 2000 / XP

Windows automatically detects your hard drive as a USB Mass Storage Device and installs the necessary drivers.

Windows 98SE

- Go to the Support page at www.kasercorp.com.
- Download the driver for your Kaser Vault model.
- Unzip the archive and double-click the Install icon.
- Follow the instructions on the screen.
- Restart your computer.

MacOS X

MacOS X automatically detects your hard drive and creates a disk icon on the desktop. The first time you use the drive you may need to format the drive for your operating system.

PortableVault

Connecting the drive

- 1 Attach one end of the USB cable to the back of the external drive and the other end to an available USB port on the back of your computer.
- 2 After Windows recognizes your external drive and assigns it a drive letter, it is ready to use.

StorageVault, MobileVault, and PortableVault drives have a light to indicate drive activity.



Disconnecting the drive

Windows

- 1 Right-click the Remove Hardware icon in the System Tray (next to the clock) and select Safely Remove Hardware.
- 2 In the Remove Hardware dialog, click on the appropriate USB drive or mass storage device and click Stop.



- 3 In the resulting dialog, click OK to confirm your selection. Click Close to close the Remove Hardware dialog.



In some cases when the drive is being used by an application (like the Windows Explorer), the drive will not be removed. Close any windows using data on the drive and repeat the procedure.

MacOS

Unmount your external drive by dragging the drive icon to the Trash Can. You can remove the drive safely once any activity light has gone out.

Setup One Button Backup

- 1 After connecting your drive, double-click its icon to open it.
- 2 Launch the Regen Backup installer by double-clicking its icon.
- 3 Follow the prompts to install Regen and run it for the first time. If Regen is already installed, select Start menu > OnSpec Regen > Regen.
- 4 Press the backup/copy button on your drive to start the Button Backup Wizard.



- 5 Follow the prompts to specify (1) the backup drive name, (2) the files or disk you want to back up, and (3) a name for the backup store.

The backup can be run immediately after setup.

Running One Button Backup

- 1 Launch the Regen, if it is not already running (check the System Tray for the Regen Icon).



Please note that Regen must be running or launched in order for the One Button feature to work properly.

- 2 Press the Backup/Copy button on your Vault drive to start the backup immediately.
- 3 The backup will proceed without user input or intervention.

©2006 Kaser Corporation. All rights reserved. Other logos, trademarks or registered trademarks are the property of their respective owners. Visit us at <http://www.kasercorp.com> for new products.